

DIGITAL LEVEL CALIBRATION INSTRUCTIONS

The calibration must be performed on a flat and smooth surface with following procedures.

- A. With the equipment turned off, press and hold the (REF) button and press the (ON/OFF) button, then (CAL) will show on the screen and disappear shortly. The calibration mode now is activated.
- B. Put the equipment, with the display facing you, on a flat and smooth surface. Press the (REF) button, the (CAL 1) icon will be shown on the screen and disappear shortly.
- C. Rotate the equipment 180° so the battery door is now facing you and place in the same location on the flat smooth surface, then press the (REF) button and (CAL 2) icon will show on the screen. When the (CAL 2) icon disappears, the calibration is completed. The LCD will show the current angle on the high accuracy display.

BEST REGARDS